

INSTALLATION GUIDE

BIOS Configuration

- · In case that the "CPU FAN ERROR" message is displayed by the UEFI (BIOS), please adjust the UEFI fan speed settings ("CPU Fan Speed Low Limit" Option).
- **Settings will vary according to your type of motherboard. Please consult your motherboard instructions.

Before Installation & Caution during Installation

- · It is recommended to reserve enough space for installing this product as well as to wear gloves to prevent any injuries during the installation.
- · Please keep this product and accessories away from children.
- · To prevent injuries, please be careful as the edges of the devices installed in your system can be sharp.


启动电脑时请注意

- · 若在电脑启动时UEFI(BIOS)显示"CPU FAN ERROR",请在UEFI(BIOS)中设定风扇转速警告。
- ※设定方式依各厂牌主机板不同,请参阅详读各厂牌主机板说明书。


安装前及使用时注意事项


- · 在安装本产品时,建议您预留从机箱中卸除主机板所需的空间,
- 并且于安装的全程配戴手套。
- ·请将本产品以及附属零件保管在孩童无法取得的地方。
- · 安装时请小心本产品以及电脑内部的尖锐处避免受伤。


PART LIST




INTEL LGA 115x









V≡ darkFlash

DARKFLASH INFOTECH CO., LTD. www.darkflash.com